

F I G. 1



F I G. 2

1	400	partition management information region
group 1	410	110
	411	switch region
	412	
	420	partition boot information region
	430	file management 130 information region
<u>.</u> ¥	440	
group 2	441	
	442	user data / 140
	443	user data region
	444	
	445	
	446	
<u> </u>	447	
1	:	
•		


F I G. 3



F I G. 4

	_	
7	800	partition management information region 700
	820	partition boot information region 720
ļ	810	
group 1	811	switch region
	812	
	830	file management 730 information region
	840	
	841	
	842	user data 740
group 2	843	user data region
	844	
}	845	
	846	
<u> </u>	847	
1	:	
•		

F I G. 5



F I G. 6

	A00	partition management information region	900
	A20	partition boot information region	920
	A30	file management information region	930
group 1	A40		
	A10		1
	A11	switch region	1
	A12		user
	A41	910	data region
group 2	A42		940
	A43		
	A44		
	A45		
	A46		
-*	A47		/
	:	:	


F I G. 7 A

entry 0001 [Reserved]	entry 0002 [FFFF]	entry 0003 [0000]
entry 0005 [0000]	entry 0006 [0000]	entry 0007 [0000]
entry 0009 [0000]	entry 000A [0000]	entry 000A [0000]
•		
	[Reserved] entry 0005 [0000] entry 0009	[Reserved] [FFFF] entry 0005 entry 0006 [0000] [0000] entry 0009 entry 000A


F I G. 7 B

entry 0000	entry 0001	entry 0002	entry 0003
[Reserved]	[Reserved]	[FFFF]	[FFF7]
entry 0004	entry 0005	entry 0006	entry 0007
[FFF7]	[FFF7]	[0000]	[0000]
entry 0008	entry 0009	entry 000A	entry 000A
[0000]	[0000]	[0000]	[0000]
	•		
	•		


F I G. 8



F I G. 9



F I G. 10



F I G. 11

600 partition management information region	- 500
I I I region I	
620 partition boot information region	· 520
630 file management information region	530
group 1 640	
641	
642	540
643 user data region	. 540
644	
645	
646	
group 2 647	
648	
649	
64A	